

Braille Me Command Guide V 1.3

Last updated on: 20/12/2017
Inceptor Technologies Pvt. Ltd. (Innovision)

Firmware version: M01.12S01.04H09.00

Global commands for Braille Me

Braille-Me Functions	Key command
PAN left	leftup
PAN right	leftdown
Next	rightdown
Previous	rightup
Back command	back
Enter command	enter
Space command	space
Keyword Search toggle	Space + dot 1
Auto-Scroll toggle	Space + dot 2
Save file contents	Space + dot 3
Backspace	Space + back
Delete	Space + enter
Previous paragraph of file	Space + dot 1 + leftup
Next paragraph of file	Space + dot 1 + leftdown
Go to start of File	Space + dot 1 3 + enter
Go to end of File	Space + dot 1 6 + enter
Yes	Back + dot 3
No	Enter + dot 6
Display time toggle	leftup + rightup

Display date toggle	leftdown + rightdown
Display battery level toggle	leftup + leftdown + rightup + rightdown
Cursor blink ON/OFF	rightup + rightdown
Cursor mode 2 toggle	leftup + leftdown
Braille Me app	Space + leftdown + rightdown
Toggle typing ON/OFF	Space + dot 1 4

Braille Back commands

Braille Back function	Key Command
home	Space + dot 3 + enter
back	Space + dot 1 2 3 4 5 6
go up one line	leftup
go down one line	leftdown
pan right	rightdown
pan left	rightup
recent apps	Space + dot 2 5
notification bar	Space + dot 5 + leftup
backspace	Space + enter
enter	enter
space	space
go left to non-blank window	Space + dot 1+ rightup
go right to non-blank window	Space + dot 1+ rightdown
go up to line with different content	Space + dot 1 3 + enter
go down to line with different content	Space + dot 1 6 + enter
go up to line with different attributes	Space + rightup

go down to line with different attributes	Space + rightdown
previous paragraph	Space + dot 1 + leftup
next paragraph	Space + dot1 + leftdown
go to top left corner	Space + dot 2 3 + enter
go to bottom left corner	Space + dot 2 6 + enter
go up several lines	Space + leftup
go down several lines	Space + leftdown
page up	Space + dot3
page down	Space + dot6
delete	Space + enter

NVDA commands

NVDA function	Key Commands
space	Space
backspace	Space + back
enter	Enter
escape	Space + dot 1 2 3 4 5 6
delete	Space + enter
Braille previous line	Leftup
Braille next line	leftdown
Braille scroll back	Rightup
Braille scroll forward	rightdown
Left Alt	Space + dot2
tab	Space + dot 5
Shift + alt + tab	Space + dot 2 4 5

Alt + tab	Space + dot 2 5
Shift + tab	Space + dot 4 5
end	Space + dot 6 + enter
Control + end	Space + dot 1 6 + enter
home	Space + dot 3 + enter
Control + home	Space + dot 1 3 + enter
Left Arrow	Space + rightup
Control + shift + left Arrow	Space + dot 1 4 + rightup
Control + left Arrow	Space + dot 1 + rightup
Shift + alt + left Arrow	Space + dot 2 4 + rightup
Alt + left Arrow	Space + dot 2 + rightup
Right Arrow	Space + rightdown
Control + shift + right Arrow	Space + dot 1 4 + rightdown
Control + right Arrow	Space + dot 1 + rightdown
Shift + alt + right Arrow	Space + dot 2 4 + rightdown
Alt + right Arrow	Space + dot 2 + rightdown
Page Up	Space + dot 3
Control + page Up	Space + dot 1 3
Up Arrow	Space + leftup
Control + shift + up Arrow	Space + dot 1 4 + leftup
Control + up Arrow	Space + dot 1 + leftup
Shift + alt + up Arrow	Space + dot 2 4 + leftup
Alt + up Arrow	Space + dot 2 + leftup
Shift + up Arrow	Space + dot 4 + leftup
Page Down	Space + dot 6

Control + page Down	Space + dot 1 6
Down Arrow	Space + leftdown
Control + shift + down Arrow	Space + dot 1 4 + leftdown
Control + down Arrow	Space + dot 1 + leftdown
Shift + alt + down Arrow	Space + dot 2 4 + leftdown
Alt + down Arrow	Space + dot 2 + leftdown
Shift + down Arrow	Space + dot 4 + leftdown
Caps Lock	Back + enter